



Red: Hard lines.

Green: Flexible lines to shock absorbers.

Blue: Flexible lines to track tensioner, lubrication point
on outside under the cover.